

JET Power-Flo
Throttle Body Spacer Installation Instructions
1999-2001 Chevrolet/GMC 2.2L
Part #62155

1. Remove Air Intake Assembly from throttle body.
2. Remove the bolts and studs that mount the throttle body to the intake manifold.
3. Install the JET Power-Flo throttle body spacer using the supplied oring between the intake manifold and throttle body .
4. Replace the 4 bolts that mounted the throttle body using the new bolts and flat washers supplied in the kit.
7. Install the extender plate at the mounting point for the air box using the allen head screws.
8. Reinstall and reconnect the linkage assembly and reconnect the cables to the throttle body.
9. Verify the throttle linkage ,cruise control and kick down cables are NOT binding and that the travel on the linkage is correct before you start the vehicle.
NOTE: In some instances it may be necessary to readjust the cables for proper travel, refer to your factory service manual for correct adjustment procedures.
8. Reinstall the Air Intake assembly.