

***JET Power-Flo***  
**Throttle Body Spacer Installation Instructions**  
**Holley 4 barrel**  
**Part #62204**

1. Remove air cleaner assembly from the carburetor.
2. Remove the throttle cables and the 4 bolts or studs that mount carburetor to the intake manifold.
3. Remove the carburetor.
4. Remove the gasket and clean any residue from the surfaces. Be careful not to get any gasket material in the intake manifold.
5. Install the JET Power-Flo throttle body spacer using one gasket between the carburetor base plate and the spacer and use the other gasket between the spacer and the intake manifold.
6. Replace the 4 bolts or studs that mounted the carburetor to the intake manifold using the new studs, flat washers and nuts supplied in the kit.
7. Verify the throttle linkage, cruise control and kick down cables are NOT binding and that the travel on the linkage is correct before you start the vehicle.  
**NOTE: In some instances it may be necessary to readjust the cables for proper travel, refer to your factory service manual for correct adjustment procedures.**
8. Reinstall the Air Cleaner assembly.

**Included in kit:**

- 1- JET Powr Flo Spacer #62204
- 2- Gaskets
- 4- 8mm washers
- 4- 5/16 - 18 x 3 ¼ studs
- 4- 5/16 - 18 nuts