

JET POWERTECH PULLEYS

PART # 90140

- 1. Remove alternator belt.
- 2. Remove belt and harmonic balancer. Note direction of cast arrow
- 3. Remove alternator pulley and spacer.
- 4. Install underdrive balancer with mark in same location as cast arrow. Install alternator pulley.
- 5. Install Gates belt #K060615 Note: you may cross reference the Gates belt # to any other brand of belt.
- 6. With the **JET** pulley kit installed, a reduction in charging at idle is normal. It is best to drive in a gear sufficient to maintain 1500 rpm or greater in order to maintain a good charge in the battery. Avoid prolonged idle especially in hot weather or with AC or headlights in use.

JET Performance Products
17491 Apex Circle
Huntington Beach, CA 92647
714-848-5515 fax 714-847-6290 www.jetchip.com