

Class III Receiver Hitch Part No. 69620C



Fits: VOLKSWAGEN TIGUAN



GROSS LOAD CAPACITY WHEN USED AS A WEIGHT CARRYING HITCH: 3,500 LBS. TRAILER WEIGHT & 525 LBS. TONGUE WEIGHT.
WARNING: *** DO NOT EXCEED VEHICLE MANUFACTURER'S RECOMMENDED TOWING CAPACITY. **



	• \									<u> </u>	
			Parts List			7	TOOLS REQUIRED				
ITEM	QTY	PART NUMBER		DESCRIPTION	١		RATCHET			HARDWARE	
1	4	10-10282	BOLT, CAR,	7/16-14 UNC,1-1	/2,GRD8,YZ	╝	TORQUE WRENCH		(M10 - 1.	.5 x 40mm IGE BOLTS)	
2	4	CM-SP2	.250 x .88 x 2	2.25" SQUARE F	HOLE SPACE	R	SAFETY GLASSES		IIEAT EAN	GE BOLIO,	
3	4	20-00103	NUT, SER-F	LANGE,7/16-14	UNC,GRD8,Y	z] L	13mm AND 16mm SOCKE	ΓS			
4	4	7_16 FISHWIRE	7/16" FISHW	IRE							
							PASSENGER SIDE F	RAME RAIL	<u> </u>	/ /	
							/	_			
								//			\ @]*
									EXISTING WELDN	,TG	
									(SOME MODELS BOTH FRAME RAI	s \	
						/			DOTTI NAME NA		
					//	//	(4)				
	C	2) ~	\bigcirc 1		//	/					
	(a /	•							
					•						
			\		DRIN	/ER S	IDE FRAME RAIL				
			·	\ '	\checkmark			//	// //	•	
		ſ		. \							
		Ø.	Soffin		\	\					
		(3)	/ //			_					
		•			.X°	\mathbb{N}					
			/0	0	ルノ	//			// //		
				\ 							
						//		/			
		WEIGHT 00 : 50						(_	
		<u>WEIGHT:</u> <u>30</u> LBS L TIME				~				ROM	
		ESSIONAL: 20 M	IINUTES	/0						201	
				· \	Jr.					N N	

INSTALLATION STEPS

NOVICE (DIY): 40 MINUTES

-NO DRILLING REQUIRED

INSTALL NOTES:

- 1. Lower exhaust by removing (2) bolts from each rear exhaust hanger brackets (1 per side) using a 13mm socket. Vehicles with factory hardware:
- 2a. Remove (4) M10-1.5 x 40mm bolts from the outside of the frame rails with a 16mm socket (2 per side).
- 3a. Raise hitch into position and reinstall the (4) M10 bolts removed in step 1. Torque all M10 bolts to 45 ft-lbs.

Vehicles without factory hardware:

- 2b. Fishwire 7/16" carriage bolt and CM-SP2 spacer through access hole in bottom of frame rails and leave in frame.
- 3b. Raise hitch into position feeding fishwires through mounting holes in hitch. Pull hardware out of frame and secure hitch with 7/16" nuts. Torque all 7/16" hardware to 59 ft-lbs.
- 4. Raise exhaust back into position and reinstall remaining fasteners removed in step 1.

PERIODICALLY CHECK THIS RECEIVER HITCH TO ENSURE THAT ALL FASTENERS ARE TIGHT AND THAT ALL STRUCTURAL COMPONENTS ARE SOUND.

Keystone Automotive Operations Inc., warrants this product to be free of defects in material and/or workmanship at the time of retail purchase by the original purchaser. If the product is found to be defective, Keystone Automotive Operations Inc., may repair or replace the product, at their option, when the product is returned, prepaid, with proof of purchase. Alteration to, misuse of, or improper installation of this product voids the warranty. Keystone Automotive Operations Inc.'s liability is limited to repair or replacement of products found to be defective, and specifically excludes liability for incidental or consequential loss or damage. This product complies with safety specifications and requirements for connecting devices and towing systems of the state of New York, V.E.S.C. Regulation V-5 and SAE J684. For Technical & Warranty Support: 1-877-544-4449 Fax-1-855-242-8922 www.huskytow.com