

MBRP

MBRP Muffler Installation Instructions 4290213

4290213

2015-2020 Polaris 800 Rush, Switchback

2015-2021 Polaris 600 Switchback

2015-2020 Polaris 600 Rush

2019-2022 Polaris 600 Indy

2019-2020 Polaris 800 Indy

2016-2020 Polaris 800 RMK, PRO-RMK, SKS

2016-2022 Polaris 600 RMK, PRO-RMK

2017-2021 Polaris 600 Voyageur

Note: Local regulations may limit or prohibit modification to your snowmobile's emissions system and/or the sound levels that it generates. It is your responsibility to be aware of restrictions that may apply to your intended use of this product.

1. Remove the side panel to access the stock muffler.
2. Remove the two springs attaching the muffler to the tuned exhaust pipe. (Set these springs safely aside so that they can be reused.)
3. Remove the spring further up the tuned exhaust pipe to allow the pipe to move freely.
4. Remove the spring on the backside of the stock muffler.
5. Remove the stock muffler from the belly pan. Be careful not to damage the gasket at the muffler inlet.
6. Remove the rubber bushing from the upper bracket of the stock muffler and transfer it onto the MBRP muffler.
7. Install the MBRP muffler in the same location as the original muffler and re-attach all springs to the spring tabs.

CAUTION: DO NOT touch the muffler while the snowmobile is running or shortly after it has run, as it may result in personal injury.

MBRP Ltd. warranty applies for a two (2) year period from the date of purchase to defects in product material and workmanship and is to the original purchaser on record and for the original vehicle for which it was designed and installed. This warranty is limited, at MBRP Ltd.'s sole determination, to the repair or replacement of defective product only and does not include the cost of removal or re-installation, damage by accident, abuse, misuse or misapplication or any consequential damages however they may arise. Determination of warranty coverage shall be at the discretion of an authorized MBRP Ltd. quality engineer.

