


S5226P

1998-2011 FORD RANGER,
1998-2009 MAZDA B3000/B4000,
3.0L/4.0L V6,
2.5" CAT-BACK, SINGLE SIDE EXIT

MBRP®



ITEM	DESCRIPTION	QTY
1	FRONT PIPE	1
2	MUFFLER	1
3	OVER-AXLE PIPE	1
4	TAIL PIPE	1
5	2.5" CLAMP	3
6	HANG TIGHT™ HANGER	1
7	SPRING BOLT KIT	1

PLEASE READ BEFORE STARTING INSTALLATION

While MBRP has made every effort to ensure that all components of this system are of superior quality and properly packaged, it is the installer's responsibility to ensure the following before removal of the factory exhaust:

- that ALL components shown above are present.
- that ALL mating components fit together.
- that there are no damaged components.
- that the system you have purchased is appropriate for your vehicle year, model and configuration.
- that the system will not interfere with any modifications previously installed or planned.
- that you have read and understand these instructions.

If you have any questions or are uncertain about any aspect of the installation of this system to your vehicle please contact your dealer before commencing installation.

MBRP

Removal of Stock System:



Figure 1

1. Apply a penetrating lubricant liberally to all exhaust fasteners, hangers and rubber insulators.

2. Remove the bolts and springs holding the front flange together and disconnect the exhaust system. **Refer to Figure 1.**

3. Remove the hangers from the rubber insulators and remove the exhaust from the vehicle. **Refer to Figures 2 & 3.**



Figure 2

Installation of MBRP Performance Exhaust:

1. Now loosely attach the **Front Pipe** to the flange using the **Spring Bolt Kit** provided. **Refer to Figure 4.**

Note: The **Extension Pipe** will need to be trimmed on some models, refer to the illustration below.



Figure 3





Figure 4

2. Install the **Hang Tight™ Hanger** onto a **3.0” Band Clamp** using the procedure shown below. (Hang Tight™ Hanger not exactly as shown).



3. ROTATE HANGER BRACKET TO SEAT THREADED STUD IN SLOT. BE SURE THE NUT IS ABOVE THE BRACKET

MBRP




Figure 5

3. Install the **Muffler** onto the **Extension Pipe** using the **Hang Tight™ Hanger Clamp Assembly**. Then install the **Hang Tight™ Hanger** into the factory rubber insulator. Do not tighten the clamp at this time. **Refer to Figure 5.**

4. Loosely install the **Over Axle Pipe** connecting it to the **Muffler** outlet with a **2-½” Clamp**. **Refer to Figure 6.**




Figure 6

5. Connect the expanded end of the **Tail Pipe** to the **Over Axle Pipe** with the remaining the **2 ½” Clamp**. Install the hanger into the factory rubber insulator. **Refer to Figure 7.**

6. Tighten all hardware and clamps, starting at the front and working rearward to secure the system. Check along the full length of the exhaust system to ensure there is adequate clearance for fuel lines, vent lines, brake lines, frame, bodywork, suspension, and any wiring, etc. If there is any interference detected, relocate, or adjust to provide adequate clearance. Ensure all clamp connections are secure and components are unable to rotate or slide. Band clamps require approximately 45 lb-ft (60 N-m) of torque. Verify clearances, system security and band clamp torque after 30-60 miles (50-100 km) of driving.



Figure 7

Congratulations! You are ready to begin experiencing the improved power, sound and driving excitement of your **MBRP** performance exhaust system. We know you will enjoy your purchase.