



ITEM	DESCRIPTION	QTY
1	DRIVER LIGHT BRACKET	1
2	PASSENGER LIGHT BRACKET	1

Refer to this **LOT NUMBER** when contacting customer service: _____

PLEASE READ BEFORE STARTING INSTALLATION

While MBRP has made every effort to ensure that all components of this system are of superior quality and properly packaged, it is the installer's responsibility to ensure the following:

- that ALL components shown above are present.
- that ALL mating components fit together.
- that there are no damaged components.
- that the system you have purchased is appropriate for your vehicle year, model and configuration.
- that the system will not interfere with any modifications previously installed or planned.
- that you have read and understand these instructions.

If you have any questions or are uncertain about any aspect of the installation of this system to your vehicle please contact your dealer before commencing installation.



Figure 1



Figure 2

1. Use tape or a pen to mark both of the hood hinge positions on the hood prior to the installation.

2. Apply tape or stretch wrap over the edges of the hood where the light brackets will be installed to protect paint during the installation.

COMPLETE BRACKET INSTALLATION ON ONE SIDE AT A TIME

3. Loosen the hood hinge nuts enough to slide the **Passenger Light Bracket** in place between the nuts and hood hinge. Disengage the washer hose retaining clip if equipped. Do not install the light brackets between the hood and hood hinge, doing so will lift the hood.

Refer to Figure 1 and 2.

4. Tighten the hood hinge nuts and position the hinge in-line with the previously marked indicators. Replace the washer hose retaining clip. **Ensure the light bracket is installed in a position where it will not contact the hood.**

Refer to Figure 1 and 2.

REPEAT STEPS 1-4 ON OPPOSITE SIDE OF VEHICLE



Congratulations! You are ready to begin outfitting your vehicle with your **MBRP** performance ditch light brackets. We know you will enjoy your purchase.