



INSTALLATION INSTRUCTIONS | PART NO. 106-0459

STEP 1: (Carefully read all instructions before installation) Disconnect the vehicle's battery before removal of the OEM exhaust system. This will prevent electrical accidents and will reset the computer if it applies to the vehicle. Remove existing exhaust system from the vehicle. Only remove parts that will be replaced. Clean existing flange with a wire brush to ensure proper sealing.

STEP 2: Attach the Resonator Assembly to the existing exhaust with the supplied Hardware and Gasket.

STEP 3: Attach the Mid pipe Assembly to the Resonator Assembly with supplied Clamp.

STEP 4: Attach the Y-Pipe Assembly to the Mid-Pipe Assembly and isolator with the supplied Clamp.

STEP 5: Attach Passenger Side Muffler Assembly to Y-Pipe Assembly and existing isolators with supplied Clamp.

STEP 6: Attach Drivers Side Muffler Assembly to Y-Pipe Assembly and existing isolators with supplied Clamp.

STEP 7: Ensure new exhaust is not contacting any portion of the underbody of the vehicle or drivetrain.

STEP 8: Tighten all clamps starting from rear of the vehicle. **(DO NOT EXCEED 30FT-LB WHEN TIGHTENING CLAMP AND CHECK ALL CLAMPS AFTER 50 MILES. RETIGHTEN IF NECESSARY)**

WARNING:

When working on, under, or around any vehicle exercise caution. Please allow the vehicle's exhaust system to cool before removal, as exhaust temperatures may cause severe burns. If working without a lift, always consult vehicle manual for correct lifting specifications. Always wear safety glasses and ensure a safe work area. Serious injury or death could occur if safety measures are not followed.



BRExhaust recommends
professional installation
for all products

Technical Support: 1-800-631-7271

BRExhaust — 1901 Corporate Ctr, Oceanside, CA 92056