



CAM-110009-2

Ford Ranger Edge/Sport 01-12 2wd Performance 6.0 Kit (FOX dual shock)

Suspension Components

- 1 Driver Side Upper Arm
- 1 Passenger Side Upper Arm
- 1 Driver Side Spindle
- 1 Passenger Side Spindle

Upper Arm Hardware

- 8 Upper Arm Bushings (# 2587)
- 4 7/8" OD x 9/16" ID x 2.225" Inner Pivot Sleeves (# 950029)
- 4 90 Degree Zerk Fittings (self tapping)
- 4 Grease Packets
- 2 5/8-18 x 4.5" G9 Bolts
- 4 5/8" SAE G8 Washers
- 2 5/8-18 Stover Nuts
- 4 1" x 5/8" Tall Mis-alignment Spacers (# 040031)

Spindle Hardware

- 2 1/4-28 x 2" G8 Bolts
- 2 1/4-28 x 3/4" G8 Bolts
- 8 1/4" SAE G8 Washers
- 4 1/4-28 Stover Nuts

Misc. Hardware & Components

- 1 Frame Gusset Kit (# 130006)
- 4 FOX 2.0 IFP Performance 8" front shocks (#985-24-004)
- 2 Upper Weld-on Shock Towers
- 2 Lower Weld-on Shock Mounts (1 left / 1 right)
- 4 1/2-13 x 5" G8 Bolts
- 2 10" Limit Straps (# 030050)
- 2 Limit Strap Frame Tabs (# 040141)
- 4 1/2-13 x 1.25" G8 Bolts
- 24 1/2" SAE G8 Washers
- 8 1/2-13 Stover Nuts
- 1 Extended Front Brake Line Kit (# 130007)
- 4 8.5" Camburg Stickers

Notes:

- 1) You must press out the OEM stock spindle pin/snout and press into the Camburg spindles. Aftermarket lift spindle pins will NOT work.
- 2) We recommend running a 31-33" tire on either a 15"-17" rim with a maximum backspacing of 4.75"
- 3) Make sure ABS wheel speed sensors and tone rings are clean from debris.