

INSTALLATION INSTRUCTIONS | PART NO. 106-0618

BILL OF MATERIALS:

STEP 1: (Carefully read all instructions before installation) Disconnect the vehicle's battery before removal of the OEM exhaust system. This will prevent electrical accidents and will reset the computer if it applies to the vehicle. Remove existing exhaust system from the vehicle. Only remove parts that will be replaced. Clean existing flange with a wire brush to ensure proper sealing.

STEP 2: Attach Drivers Side Inlet Pipe Assembly to existing exhaust flange with supplied hardware and gasket.

STEP 3: Attach Passengers Side Inlet Pipe Assembly to existing exhaust flange with supplied hardware and gasket.

STEP 4: Attach Drivers Side Muffler Assembly to Drivers Side Inlet Pipe Assembly and existing isolator with supplied clamp.

STEP 5: Attach Passengers Side Muffler Assembly to Passengers Side Inlet Pipe Assembly and existing isolators with supplied clamp.

STEP 6: Attach Drivers Side Mid Pipe Assembly to Drivers Side Muffler Assembly with supplied clamp.

STEP 7: Attach Passengers Side Mid Pipe Assembly to Passengers Side Muffler Assembly with supplied clamp.

STEP 8: Attach both Tail Pipe Assemblies to the Mid Pipe Assemblies and existing isolators with supplied clamps.

STEP 9: Ensure new exhaust is not contacting any portion of the underbody of the vehicle or drivetrain.

STEP 10: Tighten all clamps starting from rear of the vehicle. **(DO NOT EXCEED 30FT-LB WHEN TIGHTENING CLAMP AND CHECK ALL CLAMPS AFTER 50 MILES. RETIGHTEN IF NECESSARY)**

WARNING:

When working on, under, or around any vehicle exercise caution. Please allow the vehicle's exhaust system to cool before removal, as exhaust temperatures may cause severe burns. If working without a lift, always consult vehicle manual for correct lifting specifications. Always wear safety glasses and ensure a safe work area. Serious injury or death could occur if safety measures are not followed.



BRExhaust recommends professional installation for all products

Technical Support: 1-800-631-7271

BRExhaust — 1901 Corporate Ctr, Oceanside, CA 92056

www.brexhaust.com