



Toyota Tundra 00-03 2wd/4wd Long-Travel Kit [CAM-310015]

Upper Arm Hardware (1 Left Arm / 1 Right Arm)

8	Upper Arm Bushings (# 2587)
4	Inner Pivot Sleeves (7/8" OD X 9/16" ID X 2.335" OAL)
8	Large plated Washers (#970414)
4	90 Degree Zerk Fittings (self tapping)
4	Grease Packets
2	M14 x 1.50 Nyloc Nuts
2	M14 Washers
2	10-32 x 3/4" Steel SHCS Bolts
2	10-32 Steel Nyloc Nuts
4	10-32 Stainless Washers
2	Abs Wire Clamps
2	5/8-18 x 4.5" G9 Bolts
2	5/8-18 Stover Nuts
2	1" x 5/8" Mis-alignment Spacers (top) (#960003)
2	Uniball Spindle Adaptors (bottom) (#960012)
2	Spindle Adaptor Snap Rings

Lower Arm Hardware (1 Left Arm / 1 Right Arm) (Small Taper)

4	Inner Pivot Uniball Front Mount Spacers (long) (#960034)
4	Inner Pivot Uniball Rear Mount Spacers (short) (#960035)
2	1/2-13 x 2.5" G8 Bolts
4	1/2 SAE G8 Washers
2	1/2-13 Stover Nuts

Misc. Hardware & Components

2	12" Limit Straps
2	Limit Strap Frame Tabs
4	1/2-13 x 1.25" G8 Bolts
8	1/2" SAE G8 Washers
4	1/2-13 Stover Nuts
1	Extended Front Brake Line Kit (#330002)
2	M18 x 1.5 Steering Extensions (#960049)
2	Upper Coilover Mounting Plates
2	Coilover Remote Res. Frame Mounts (1L & 1R)
2	1/2-13 x 4.5" G8 Bolts
4	1/2" SAE G8 Washers
2	1/2-13 Stover Nuts
6	3/8-24 x 1" G8 Bolts
12	3/8" SAE G8 Washers
6	3/8-24 Stover Nuts
4	8.5" Camburg Stickers

Notes:

- 1) Grind the nubs that hang down from the lower ball-joint as it can scratch the powdercoat on the lower arms at full droop (extension).
- 2) Check upper arm clearance on the backside of the coil bucket. You may need to grind the edge back an 1/8".
- 3) We recommend running a 33"-34" tire on either a 16" or 17" rim with a maximum backspacing of 4.75"
- 4) We recommend using a 16" x 600# coil, on the correct Fox or King 8" travel shocks. Shocks must have a 90 degree fitting on the top cap, a raised lower spring seat and 1.25" shock spacers.
- 5) We recommend using 2.0 x 2"-2.5" bumpstops.
- 6) Fiberglass front fenders are required.