



INSTRUCTIONS:

1. ASSEMBLE MOUNTING BRACKETS TO FAN BY TAPPING INTO PLACE WITH A RUBBER OR PLASTIC HAMMER.
2. POSITION FAN ON HEAT EXCHANGER.
3. MAKE PASSAGEWAY THRU HEAT EXCHANGER FINS USING #1 PHILLIPS SCREWDRIVER. USE HAND PRESSURE ONLY, INSURING THE HEAT EXCHANGER IS NOT DAMAGED.
4. SLIDE THE TIE STRAP THRU THE MOUNTING BRACKET, SPACER, AND HEAT EXCHANGER AS SHOWN. SECURE WITH PLASTIC LOCK ON OPPOSITE SIDE OF THE HEAT EXCHANGER AS SHOWN.

DISCLAIMER

1. THE KITS OF THIS KIND ARE POPULAR WITHIN THE MARKETPLACE, AND ARE PROVIDED AS A SERVICE TO OUR CUSTOMERS ONLY. IT IS THE INSTALLER'S RESPONSIBILITY TO DETERMINE SUITABILITY FOR THE INDIVIDUAL APPLICATION. WE WILL NOT ACCEPT LIABILITY FOR DAMAGED HEAT EXCHANGERS, OR FANS LOOSENING DURING USE.
2. THE KITS ARE NOT RECOMMENDED FOR USE ON FANS LARGER THAN 12" DIAMETER AND/OR 130 WATTS NOMINAL INPUT.