

# SILVER SPORT

## Transmissions

### SPEEDOMETER CABLE ASSEMBLY INSTRUCTIONS

FOR ALL SILVER SPORT AUTOMATIC OR MANUAL TRANSMISSIONS WITH A MECHANICAL SPEEDOMETER CABLE

1. Remove the drive cable from the speedometer cable housing by pulling it out of the speedometer end of the housing.
2. Lubricate the drive cable moderately with speedometer cable grease (provided).
3. Reinsert the drive cable into the housing from the speedometer end.
4. Lightly lubricate the large O-ring with the correct type of transmission fluid for your particular transmission.
5. Install the large O-ring over the end of the cable so that it is completely seated in the wide groove on the body of the speedometer cable.
6. **IMPORTANT!!!** Pack the transmission end of the speedometer cable housing heavily with wheel bearing grease. Install the small O-ring on the transmission end of the drive cable. It will be a very loose fit.
7. Install the speedometer gear over the same end of the cable so that the drive cable fits into the square hole inside the plastic gear.
8. Insert the retaining clip into the slots on the back side of the speedometer gear with the lip on the clip pointing away from the transmission. It will be a snug fit and you may have to push lightly on the speedometer gear in order to compress the small O-ring.
9. Rotate the speedometer gear. There should be a small amount of drag. If the gear is difficult to turn: remove retaining clip and gear, ensure that the small O-ring is not pinched, and then reassemble.
10. Attach the opposite end of the cable to your speedometer.
11. Remove the rubber or plastic plug from the speedometer output port on the left side of your transmission.
12. Insert the gear end of the speedometer cable into the transmission. Install the retaining bolt and lock washer, torque to 5 ft/lbs.
13. Continue with your transmission installation.

