

INSTRUCTIONS

1) FOR STANDARD TIMING:

-Install gear on crankshaft using keyway marked "0"

-Align "0" mark on crank gear tooth with timing mark on cam gear.

This is the same as O.E.M. setting.

2) FOR +4° or A for Advance

-Install gear on crankshaft using keyway marked "Δ" (Triangle), "+4", or "A"

-Align "Δ", "+4", or "A" mark on crank gear tooth with timing mark on cam gear.

3) FOR -4° or R for Retard

-Install gear on crankshaft using keyway marked "▢" (Rectangle or Bar), "-4", or "R".

-Align "▢", "-4", or "R" mark on crank gear tooth with timing mark on cam gear.