

The enclosed chain may not have the timing links identified. To mark these links, lay chain flat and straight. Mark a side bar link, count over 20 side bar links and mark the following two links as shown.

