

# MISHIMOTO

## INSTALLATION STEPS:

1. PLACE MM10097 INTO THE CENTER OF PASSENGER SIDE TOW HOOK.
2. PLACE MM10094-01 ON TOP OF THE TOW HOOK.
3. INSERT TWO HF8X1.25-45 BOLTS THROUGH MM10094-01 AND MM10097.
4. HOLD MM10094-02 UNDER THE TOW HOOK AND SECURE IT IN PLACE WITH THE BOLTS INSTALLED IN THE PREVIOUS STEP.
5. FASTEN MM10001-02 TO MM10094-01 IN THE DESIRED ORIENTATION USING THE PROVIDED BF8X1.25-16B BOLTS.
6. FASTEN YOUR LICENSE PLATE TO MM10001-02 USING THE PROVIDED BF6X1.0-12B BOLTS.

4X BF6X1.0-12B

2X BF8X1.25-16B

MM10001-02

2X HF8X1.25-45

MM10094-01

MM10097

MM10094-02

BILL OF MATERIALS		
PART NUMBER	DESCRIPTION	QUANTITY
MM10094-01	TOP BRACKET	1
MM10097	FOAM SPACER	1
MM10094-02	BOTTOM BRACKET	1
HF8X1.25-45	M8 HEX HEAD FLANGED BOLT	2
MM10001-02	PLATE HOLDER	1
BF8X1.25-16B	M8 BUTTON HEAD FLANGED BOLT	2
BF6X1.0-12B	M6 BUTTON HEAD FLANGED BOLT	4

