

Included:

- Aluminum Trigger Mount
- 4 x 6/32 screws and nuts
- 2 x 8 mm hex head Bolts
- 2 x flat washers

Installation:

- 1) Place the flat washers on the 8 mm bolts and insert into the mounting holes on the mount. **NOTE:** It can be difficult to install them once the Trigger is in place.
- 2) Use 6/32" screws/nuts to install the Trigger on the mount.
- 3) Install mount/Trigger onto the factory holes under the hood on the driver side, just behind the fuse box. See picture below for location detail. Use fingers to start then open end wrench to tighten.



NOTE: Route wires as required depending on installation requirements.