

**PRW POWER**1722 Illinois Avenue  
Perris, California 92571

Phone: (951) 436-7900

Tech: (888) 377-9779

**FLEXPLATE BOLT INSTALLATION****PART NUMBER: 1036310**

<i>COMPONENTS</i>	<i>QTY</i>
BOLTS	10

1. Make sure there is an adequate chamfer around the bolt holes on the flexplate to clear the radius under the head of the bolt.
2. Lube threads of the bolt with Blue threadlocker. Install the flexplate onto the crankshaft and hand tighten the bolts.
3. Torque the bolts to **70** ft.lbs using an alternating or criss-cross pattern.

GET MORE INFO, VISIT US ONLINE

**SHOP 24/7 [PRWPOWER.COM](http://PRWPOWER.COM)**

NEED HELP? GIVE US A CALL!

**TOLL FREE: (888)377-9779**