



**PRW POWER**

1722 Illinois Avenue  
Perris, California 92571

Phone: (951) 436-7900

Tech: (888) 377-9779

**HARMONIC BALANCER**  
**BOLT INSTALLATION**  
**PART NUMBER: 1039104**

<i>COMPONENTS</i>	<i>QTY</i>
BOLTS	4

1. Make sure there is an adequate chamfer around the bolt holes on the flexplate to clear the radius under the head of the bolt.
2. Install washer (if supplied) and hand tighten the bolt.
3. Torque the bolts to **115ft.lbs.**

GET MORE INFO, VISIT US ONLINE

**SHOP 24/7 PRWPOWER.COM**

NEED HELP? GIVE US A CALL!

**TOLL FREE: (888)377-9779**