



PRW POWER

1722 Illinois Avenue
Perris, California 92571

Phone: (951) 436-7900

Tech: (888) 377-9779

HARMONIC BALANCER

BOLT INSTALLATION **PART NUMBER: 1042351**

COMPONENTS	QTY
BOLTS	1

1. Make sure there is an adequate chamfer around the bolt holes on the flexplate to clear the radius under the head of the bolt.
2. Install washer (if supplied) and hand tighten the bolt.
3. Torque the bolts to **125ft.lbs.**

GET MORE INFO, VISIT US ONLINE

SHOP 24/7 PRWPOWER.COM

NEED HELP? GIVE US A CALL!

TOLL FREE: (888)377-9779