



PRW POWER
1722 Illinois Avenue
Perris, California 92571

Phone: (951) 436-7900
Tech: (888) 377-9779

CYLINDER HEAD STUD INSTALLATION

PART NUMBER: 1044021

COMPONENTS	QTY
7/16" MEDIUM STUDS	10
7/16" SHORT STUDS	24
12 PT NUTS	34
WASHERS	34
ASSEMBLY LUBE	1

FASTENER INSTALLATION:

1. Inspect kit for damage and confirm correct quantities.
2. Please clean all dirt and debris from engine block holes and threads.
3. Make sure all mating surfaces are flat, clean, and dry of any cleaning related products. Install the head gasket and cylinder head.
4. Hand-tighten (no tools and no lube) studs. Remove fasteners and clean or repair threads if necessary.
5. Liberally add supplied assembly lube to the entire threaded length of the fastener. Thoroughly work lube into all of the threads. When applying lube to bolts, please lube under the bolt head and threaded area. Apply lube to nuts on the bearing surface.
6. Install studs into block by hand.

Torque Recommendations

Follow applicable OEM/aftermarket manufacturers suggested torque sequence and number specifications. Torque fasteners in 3 equal incremental steps until final torque specification is reached. The torque values provided are for the supplied lubricant only, other lubricants may need more or less torque and are not recommended.

7/16 STUDS:
Torque: 75ft/lb