

**PRW POWER**1722 Illinois Avenue
Perris, California 92571

Phone: (951) 436-7900

Tech: (888) 377-9779

FLEXPLATE BOLT INSTALLATION***PART NUMBER: 1050101***

<i>COMPONENTS</i>	<i>QTY</i>
BOLTS	6

1. Make sure there is an adequate chamfer around the bolt holes on the flexplate to clear the radius under the head of the bolt.
2. Lube threads of the bolt with Blue threadlocker. Install the flexplate onto the crankshaft and hand tighten the bolts.
3. Torque the bolts to **28** ft.lbs using an alternating or criss-cross pattern.

GET MORE INFO, VISIT US ONLINE

NEED HELP? GIVE US A CALL!

SHOP 24/7 PRWPOWER.COM**TOLL FREE: (888)377-9779**