



Technical Support Line: (952) 985-5675 Email: sales@QA1.net

INSTALLATION INSTRUCTIONS


QA1 P/N 52871, 52878 Rear Sway Bar
1964-1972 GM A-Body, 78-88 A/G-Body

TOOLS AND SUPPLIES REQUIRED



- Floor jack and jack stands
- Wrenches
- Blue Loctite™
- Ratchet and Sockets

Installation Instructions

1. Raise and support the vehicle with jack stands on a stable surface. *Note: Never rely on a jack alone to support a vehicle.*
2. Examine how the OEM sway bar is installed. **(Figure 1)** The arrangement and orientation of the hardware can be critical for proper clearance and operation. The location and support of the parking brake cable should also be noted.
3. Unbolt and remove the OEM sway bar taking caution to keep any and all spacers. **CAUTION: Sway bars are heavy steel parts that can cause injury if unsupported during removal or installation.**



Note: Vehicles not originally equipped with a rear sway bar will require boxed trailing arms such as QA1 #5204 or #5205 for best performance. OEM boxed arms for '64-'72 A-bodies can be used on those model years (Figure 2). 1978-'88 A/G bodies used spacers in the rear trailing arms (See arrow in Figure 3) which will be required to complete the installation of the QA1 rear sway bar in those vehicles using OEM trailing arms.



4. Use a small pry bar to spread the sway bar mounting blocks. Install the mounting blocks onto the QA1 sway bar (two per side). See **Figure 4**.
5. Use the supplied hardware to install in the following order:
 - a. Place one thick washer onto bolt, and then slide the bolt through trailing arm (and OEM spacer if applicable) towards the center of the car.
 - b. Install the QA1 sway bar with mounting blocks onto the bolts, followed by the thick washers, then the locking nuts.
 - c. Thread locker is recommended for final installation, but do not fully tighten the nuts at this time.
6. Adjust the sway bar so that it fits squarely in the vehicle. The best way to ensure that the sway bar is mounted securely is by measuring from the first bend in the sway bar to the rear surface of the mounting block, verifying that the measurements are the same for both sides.



Figure 4

7. Due to variances from vehicle to vehicle your sway bar will include two thicker (.120") shims and two thinner (.060") shims. (**Figure 5**) Install one thick shim on each side between mounting blocks and trailing arm. If necessary, use the remaining thin shims to take up any gap between blocks and trailing arms. (**Figure 6**) **DO NOT USE THE MOUNTING BOLTS TO DRAW THE SWAY BAR IN TO THE ARM.**




Figure 5




Figure 6

8. Torque the mounting hardware to 40 lb.-ft. at this time.
9. Check for any contact with brake lines, electrical wiring, fuel lines or cables. Adjust the sway bar as needed.

Note: It is best to use sway bars that have been designed to work together. Never drive a vehicle with only a rear sway bar installed, as this can cause a dangerous over steer condition.





READ ALL INSTRUCTIONS CAREFULLY AND THOROUGHLY PRIOR TO STARTING INSTALLATION. PRODUCTS THAT HAVE BEEN INSTALLED ARE NOT ELIGIBLE FOR RETURN. USE THE PROPER JACKING LOCATIONS. DEATH OR SERIOUS INJURY CAN RESULT IF INSTRUCTIONS ARE NOT CORRECTLY FOLLOWED. A GOOD CHASSIS MANUAL, AVAILABLE AT YOUR LOCAL PARTS STORE, MAY ALSO AID IN YOUR INSTALLATION.

• **DISCLAIMER / WARRANTY** •

QA1 WARRANTS THAT THE PRODUCTS WILL BE FREE FROM DEFECTS IN MATERIAL AND WORKMANSHIP FOR ONE YEAR FROM DATE OF SALE TO THE ORIGINAL PURCHASER. QA1 MAKES NO OTHER WARRANTY OF ANY KIND, EXPRESS OR IMPLIED. QA1 SHALL HAVE NO OBLIGATION UNDER THE FOREGOING WARRANTY WHERE THE DEFECT IS THE RESULT OF IMPROPER OR ABNORMAL USE, YOUR NEGLIGENCE, VEHICLE ACCIDENT, IMPROPER OR INCORRECT INSTALLATION OR MAINTENANCE, NOR WHEN THE PRODUCT HAS BEEN REPAIRED OR ALTERED IN ANY WAY. QA1'S LIABILITY IN THE CASE OF DEFECTIVE PRODUCTS SUBJECT TO THE FOREGOING WARRANTY SHALL BE LIMITED TO THE REPAIR OR REPLACEMENT, AT QA1'S OPTION, OF THE DEFECTIVE PRODUCTS.

THE USER UNDERSTANDS AND RECOGNIZES THAT RACING PARTS, SPECIALIZED STREET ROD EQUIPMENT, AND ALL PARTS AND SERVICES SOLD BY QA1 ARE EXPOSED TO MANY AND VARIED CONDITIONS DUE TO THE MANNER IN WHICH THEY ARE INSTALLED AND USED. QA1 SHALL BEAR NO LIABILITY FOR ANY LOSS, DAMAGE OR INJURY, EITHER TO A PERSON OR TO PROPERTY, RESULTING FROM THE INSTALLATION, DIRECT OR INDIRECT USE OF ANY QA1 PRODUCTS OR INABILITY BY THE BUYER TO DETERMINE PROPER USE OR APPLICATION OF QA1 PRODUCTS. WITH THE EXCEPTION OF THE LIMITED LIABILITY WARRANTY SET FORTH ABOVE, QA1 SHALL NOT BE LIABLE FOR ANY CLAIMS, DEMANDS, INJURIES, DAMAGES, ACTIONS, OR CAUSES OF ACTION WHATSOEVER TO BUYER ARISING OUT OF OR CONNECTED WITH THE USE OF ANY QA1 PRODUCTS. MOTORSPORTS ARE DANGEROUS; AS SUCH, NO WARRANTY OR REPRESENTATION IS MADE AS TO THE PRODUCT'S ABILITY TO PROTECT THE USER FROM INJURY OR DEATH. THE USER ASSUMES THAT RISK!

Dedicated Technical Support Team

QA1 is dedicated to providing quality support and instructions. We employ passionate racers and car enthusiasts that know our products and the industry to better serve you.

Check out our tech videos at www.YouTube.com/QA1Tech for:

- Frequently Asked Questions
- Quick Tips
- Install Information
- Tuning and Repair Guides
- Other technical information

Or call to speak with one of our experts: 1.800.721.7761

*Our technical support and order lines are open Monday - Friday, 8 am to 5 pm CST.

 [Facebook.com/QA1Motorsports](https://www.facebook.com/QA1Motorsports)

 [Twitter.com/QA1Motorsports](https://twitter.com/QA1Motorsports)

 [Instagram.com/QA1Motorsports](https://www.instagram.com/QA1Motorsports)



www.QA1.net/Tech