

# ***BEDRUG, Inc.***

## **BEDRUG® BEDLINER INSTALLATION INSTRUCTIONS SUPPLEMENT FOR INSTALLATION OVER SPRAY ON BEDLINER**

### **WARNING: IMPROPER INSTALLATION WILL RESULT IN LINER FLYING OUT OF THE TRUCK! FOLLOW INSTRUCTIONS EXACTLY!**

1. This instruction guide is to be used in conjunction with the instruction sheet included with the BedRug.
2. Follow the installation sequence as instructed on the instruction sheet included with the BedRug.
3. Scuff the spray in liner areas where the hook fasteners are to be attached using steel wool or sandpaper. This must be done to provide a very rough surface for the adhesive to adhere to.
4. Using a cloth, soap and water, clean and dry this area thoroughly removing all dirt and debris. With a separate cloth, clean the area again with alcohol. After cleaning all surfaces with alcohol, apply the adhesive promoters included in this kit to a lint free cloth then apply a thin layer to all areas where the hook fasteners are to be attached. Be sure to allow the adhesive promoter to dry completely before adhering hook fasteners. \*See adhesive promoter information on the promoter package.

**Note:** Attach hook fasteners immediately after the adhesive promoter has evaporated completely.

5. The fourteen (14), 1"x2" hook fasteners included in this kit are to be used in place of the long (60"+) continuous hook fasteners in the installation kit included with the BedRug.
6. Use 5-7 pieces of these 1"x2" hook fasteners in place of the long hook fasteners on the top edge of the bulkhead panel and the tailgate panel.

**Note:** The long strips of hook fastener will not adhere properly to the spray on bedliner surface.

USE (5 - 7) 1" X 2" PIECES IN  
PLACE OF THE 60"+  
CONTINUOUS STRIP  
SUPPLIED IN THE  
STANDARD KIT ALONG  
THE UPPER EDGE OF THE  
TAILGATE & THE  
BULKHEAD.

