

PART NO. 67300

Instruction Sheet

JOUNCE SPACERS

This part should only be installed by personnel who have the necessary skill, training and tools to do the job correctly and safely.

Incorrect installation can result in personal injury, vehicle damage and / or loss of vehicle control.

Attention:

These “c” shaped Jounce Spacers are to be used as additional bump stops if needed. If the control arm contacts body on sharp compression of the suspension add the bumpstop spacers around the shaft of the strut. Install the spacers below the existing bumpstop. If light contact is noted, start with 1 spacer on each front strut. If heavier contact occurs, use 2 spacers on each front strut.



**Specialty
Products
Company®**

P.O. Box 923 • Longmont, CO 80502 • (303) 772-2103

www.specprod.com • www.spcperformance.com

Email: info@specprod.com

Toll Free Technical Hot Line: 1-800-525-6505

©2011 Niwot Corp. dba Specialty Products Co. • Printed in U.S.A. • Form No. 98122 • Rev. 12/11