

PART NO. 67493

Instruction Sheet

HYUNDAI SANTA FE CAMS

Before beginning alignment check for loose or worn parts, proper tire pressures, and odd tire wear patterns. Replace any loose or worn parts.

Plan Ahead - Read All Instructions BEFORE installing part.

1. Raise and support rear of vehicle
2. Remove upper or lower cam bolt, then loosen outer end of control arm, if necessary, and drop out of way.
3. Using **#85130 Rotary File Set** or similar, elongate factory cam slot to edges of factory reaction bracket.
4. Reinstall factory control arm and install SPC Cam Bolt and Cams, lightly tightening cam nut.
5. Repeat procedure for other control arm.
6. Lower vehicle and adjust toe and camber. When all adjustments are made, tighten all bolts to manufacture's specifications.
7. Complete vehicle alignment and road test.

This part should only be installed by personnel who have the necessary skill, training and tools to do the job correctly and safely. Incorrect installation can result in personal injury, vehicle damage and / or loss of vehicle control.



**Specialty
Products
Company®**

P.O. Box 923 • Longmont, CO 80502 • (303) 772-2103
www.specprod.com • www.spcperformance.com

Email: info@specprod.com

Printed in U.S.A. ECN#1690

Toll Free Technical Hot Line: 1-800-525-6505

©2014 Niwot Corp. dba Specialty Products Co. • Form No. 98493WEB • Rev. 8/14