

# PART NO. 67575

## Instruction Sheet

### HONDA PILOT REAR TOE CAM

*This part should only be installed by personnel who have the necessary skill, training and tools to do the job correctly and safely. Incorrect installation can result in personal injury, vehicle damage and / or loss of vehicle control.*

**Plan Ahead - Read All Instructions BEFORE installing part.**

*Check for loose or worn parts, proper tire pressure, and odd tire wear patterns before beginning alignment.*

1. Raise rear of vehicle and properly support by frame. Place a screw jack under coil spring seat to support lower control arm during toe cam removal and reinstallation.

**CAUTION: Always use appropriate safety devices to support the weight of the vehicle while servicing any suspension component.**

2. Remove OE toe cam attaching trailing arm to subframe per OEM instructions.
3. Install cam bolt by placing one cam at head of bolt, sliding the bolt through the subframe and lower control arm, then placing second cam washer and locknut on bolt. Loosely tighten nut, making sure cam washers sit in recess of subframe brackets.

**NOTE: Tightening fasteners with vehicle in raised position may cause premature bushing failure.**

4. Remove screw jack and lower vehicle.
5. Adjust toe by rotating head of bolt. Once desired setting is obtained, tighten nut to 123 ft-lb [168 Nm] while holding bolt head to preserve alignment settings.
6. Complete alignment and road test vehicle.

**Always check for proper clearance between suspension components and other components of the vehicle.**