

PART NO. 84095

Instruction Sheet

KIA / HYUNDAI REAR CAM KIT

This part should only be installed by personnel who have the necessary skill, training and tools to do the job correctly and safely. Incorrect installation can result in personal injury, vehicle damage and / or loss of vehicle control.

Plan Ahead - Read All Instructions BEFORE installing part.

Check for loose or worn parts, proper tire pressure, and odd tire wear patterns before beginning alignment.

1. Raise and support vehicle by frame.
2. Pre-assemble SPC cam bolt by placing one cam washer against head of bolt.
3. Remove OE camber bolt per manufacturer's procedure.
4. Install bolt through control arm, install second cam washer, install nut, and tighten lightly. Ensure washers sit within brackets of frame.

NOTE: Tightening fasteners with vehicle in raised position may cause premature bushing failure.

5. Lower vehicle.
6. Adjust cam bolt to desired camber setting by turning head of bolt. Torque nuts to 115 ft-lb (156 Nm) while holding head of bolt to preserve alignment setting.
7. Complete alignment and road test vehicle.

Always check for proper clearance between suspension components and other components of the vehicle.



**Specialty
Products
Company®**

4045 Specialty Pl • Longmont, CO 80504 • (303) 772-2103

For warranty information go to: www.specprod.com/warranties

www.specprod.com • Email: info@specprod.com Printed in U.S.A.

Toll Free Technical Hot Line: 1-800-525-6505

ECN#3224

©2022 Niwot Corp. dba Specialty Products Co. • Form No. 84095INS • Rev. 11/22