

## **PART NO. 87535** Instruction Sheet

### **THUNDERBIRD, MARK VIII & COUGAR CAM BOLT KIT**

*This part should only be installed by personnel who have the necessary skill, training and tools to do the job correctly and safely. Incorrect installation can result in personal injury, vehicle damage and / or loss of vehicle control.*

1. Raise vehicle by frame and support securely.
2. Remove OE inner bolt from lower camber arm.
3. Install one cam onto milled bolt and replacement OE bolt.
4. Install 2nd cam and nut onto bolt and loosely tighten.
5. Lower vehicle to ground.
6. Adjust camber by rotating bolt head.
7. Torque cam bolt to 80 ft-lb.

**Always check for proper clearance  
between suspension components and  
other components of the vehicle.**

8. Complete alignment and road test vehicle.



**Specialty  
Products  
Company**

P.O. Box 923 • Longmont, CO 80502 • (303) 772-2103  
www.specprod.com • www.spcperformance.com

Email: info@specprod.com

Printed in U.S.A.

**Toll Free Technical Hot Line: 1-800-525-6505**

©2013 Niwot Corp. dba Specialty Products Co. • Form No. 875351W • Rev. A 2/13