

INSTALLATION INSTRUCTIONS
TAIL LIGHT GUARD
2003-2010 HONDA ELEMENT

STEELCRAFT

**TAIL LIGHT GUARD
2003-2010 HONDA ELEMENT**

PARTS LIST

- 1- TAIL LIGHT GUARD PASSENGER SIDE
- 1- TAIL LIGHT GUARD DRIVER SIDE
- 4- M5-1.0 X 30mm SCREWS
- 2- #6 X 1/2" SCREWS
- 2- SUPPORT BRACKETS

INSTALLING TAILLIGHT GUARD

- (1) OPEN REAR HATCH TO ACCESS REAR TAIL LIGHT LENSE AND HOUSING. REMOVE THE FACTORY SCREWS (DISCARD SCREWS) THEN CAREFULLY PULL ON TAIL LIGHT LENSE UNTIL IT IS FREED FROM THE HOUSING.
- (2) POSITION APPROPRIATE TAIL LIGHT GUARD OVER HOUSING AND ALIGN HOLES IN UPPER AND LOWER MOUNTING BRACKET (WELDED) ON TAIL LIGHT GUARD WITH THOSE ON VEHICLE SIDE JAMB. WHILE HOLDING TAIL LIGHT GUARD ALIGN SUPPORT BRACKET (SEE DIAGRAM) ATTACH SUPPORT BRACKET TO INNER LENSE STUB TO SNAP INTO PLACE.
- (3) RE-INSERT TAIL LIGHT LENSE INTO HOUSING AND SNAPPING INTO PLACE SECURE TAIL LIGHT LENSE AND TAIL LIGHT GUARD ASSEMBLY TO JAMB USING M5 – 1.0X30mm SCREWS AND #6 X 1/2" SCREWS
- (4) REPEAT STEPS 1 THOUGH 3 ON OPPOSITE SIDE.