



GLASS PACK MUFFLER

Installation Instructions

REQUIRES PROFESSIONAL INSTALLATION



Required Tools:

- Sawzall
- Pry Bar
- Rubber Mallet
- Socket Wrench
- Various Size Sockets
- WD40
- High Temp Silicone
- Safety Glasses

Instructions: (Read thoroughly prior to starting installation; Street Series strongly recommends professional installation on all products.)

1. Begin by removing the factory muffler with an electric Sawzall. It would help if you completely cut the inlet tube off the factory inlet pipe connected to the muffler. The original factory inlet pipe connecting to the catalytic converter is the only tubing that should remain in place. Repeat the same process for the outlet tube on the original factory muffler. The only tubing remaining should be the factory outlet pipe. A rubber mallet, pry tool, and WD-40 will assist you with removing all factory joints and hangers. **Please note that some factory mufflers have hangers welded to them. Cutting and welding may be required from a professional installation center.**
2. Position your new Street Pack unit and carefully assess the optimal placement location. Please note that it is very common for the Street Pack unit to be shorter or longer than the factory muffler. If the Street Pack unit is shorter, you may need an extension pipe to make up the length. Once the Street Pack unit has been properly positioned, tack weld the unit while securely supporting it with a muffler stand. Once the unit is set in place, proceed with a full mig-weld around all connections. High-temp silicone will further seal all connections. **Remember to check for clearance of all brake and fuel lines, as well as clearance of all chassis and frame components.**
3. Inspect the installation for any exhaust leaks.



Safety is ALWAYS the Priority!

- Ensure that the engine and exhaust system have completely cooled off prior to working on the vehicle.
- Check that the vehicle is in a stable position and secured properly.
- Mechanics gloves are highly recommended for ease of factory exhaust removal and additional protection.
- Wearing eye protection is highly recommended. Either safety goggles and/or a face shield.
- If you intend on welding, a welder's helmet and heat resistant welding gloves are highly recommended! This will provide additional face, neck, eye, and hand protection.

Thank You for Choosing Street Series

Thank you for choosing Street Series! Our mission is to deliver high-quality performance exhaust products to performance enthusiasts all over the world. Whether it's for a daily driver, race application, or recreational vehicle, our goal is to maximize horsepower and torque gains while producing a rich performance tone.

Most importantly, we're committed to delivering the ultimate customer experience on all levels! Premium quality, a positive user experience, and products fully backed by a 3-year limited warranty, our customers come first!

Visit us online at street-performance.com