


1. Attach small plate to stud behind power steering pump with lock washer.



2. Attach bracket with 1-1/4" bolt with 7/16" spacer to bottom of the bracket. Attach 1" bolt with back spacer to adjustable slide of the bracket.



3. Align both front and rear brackets place 2-3/4" spacer in between both brackets. Place 1/2" spacer between block and small plate. Place socket head bolt with washer through both holes and tighten.



4. Tighten lower bolt on power steering pump. Adjust power steering pump position and tighten upper bolt.

