



# 3" Bull Bar

## Part No. B0017B



Fits: 2002-2006 Chevrolet Avalanche 2500 (with or without cladding)

1999-2007 Chevrolet Silverado 99-06, 07 "Classic"2500LD (Excl S.S. model)

2001-2007 Chevrolet Silverado 01-06, 07 "Classic1500HD/2500HD/3500 (Excl S.S. model) 1500LD


2000-2006 Chevrolet Suburban/Tahoe/GMC Yukon/Yukon XL 2500 (Excl. Denali)



REMOVE CONTENTS FROM BOX. VERIFY ALL PARTS ARE PRESENT.



READ INSTRUCTIONS CAREFULLY BEFORE STARTING INSTALLATION.



DO NOT OVER TORQUE. STANDARD OPERATING LOAD FOR TIGHTEN BODY MOUNT NUTS & BOLTS VARIES FROM 45 TO 65 FOOT POUND.



30-60 min



Cutting Required



Drilling Not Required



support@trailfx.com



1 866 638 4870



POLISHED STAINLESS STEEL – LIMITED LIFETIME  
POWDER COATED BLACK – 3 YEARS

### PARTS LIST:

Qty	Part Description	Qty	Part Description
1	Bull Bar	4	12mm x 40mm Hex Head Bolts
1	Driver Side Bracket	4	12mm Hex Nuts
1	Passenger Side Bracket	4	10mm Lock Washers
2	12mm Spacer Plate	8	10mm Flat Washers
4	12mm Lock Washers	4	10mm x 35mm Hex Head Bolts
4	12mm Flat Washers	4	10mm Hex Nuts



Passenger Side Bracket



Driver Side Bracket

### INSTALLATION PROCEDURE

- NOTE:** It may be necessary to remove/relocate front license plate and license plate bracket. It is not required, but strongly recommended. If local/state laws requires a license plate.
- Determine passenger and driver brackets. From underneath vehicle, remove tow hooks. Slide brackets through end of frame and align holes in bottom of frame with the two nuts welded to the brackets. Attach brackets to frame rail with 12mm fasteners as shown. **NOTE:** Use one spacer plate for large hole in bottom of frame as shown. Leave loose. **NOTE:** For vehicles without tow hooks a small opening may need to be cut out in the two inside indents of the air dam using a utility knife. (SEE Figure 1).
- Attach hoop mount brackets to frame brackets using 10mm fasteners as shown. **NOTE: 99-02 models** use front and middle holes on hoop mounting brackets. **03-UP models** use middle and rear holes.
- Level and adjust Bull Bar as desired. Torque 12mm fasteners and 10mm fasteners.

**Driver Side Installation Pictured**

- (2) 10mm x 35mm Hex Bolts
- (4) 10mm Flat Washer
- (2) 10mm Lock Washer
- (2) 10mm Hex Nut

**Remove Tow Hook**

**99-02 models**

**03-UP models**

**Driver Side Bracket**

**12mm Spacer Plate**

**Fig 1**

- (2)12mm Flat Washers
- (2)12mm Lock Washers
- (2)12mm Hex Nuts

**PRODUCT CARE**

- Periodically check the product to ensure all fasteners are tight and components are intact.
- Regular waxing is recommended to protect the finish of the product.
- **Use ONLY Non-Abrasive automotive wax.** Use of any soap, polish or wax that contains an abrasive is detrimental and can scratch the finish leading to corrosion.
- Aluminum polish may be used to polish small scratches and scuffs for **Stainless Steel finish.**
- Mild soap may be used to clean the product for both **Stainless Steel and Black finish.**

**FAQ's****1. Hardware's are not of correct size.**

*In GMC / Chevrolet truck model 2006 & up, customer needs to reuse the factory body bolts to install the bracket. If your vehicle is not GMC / Chevrolet 2006 & up, ensure that holes are not partially covered with any plastic grommet or rust? If it is, remove the plastic grommet & rust from the thread holes & re-try the installation.*

**2. Mounting Bracket are not getting Installed properly.**

*In some cases Illustration images shown in Installation manual may not be the exactly same as per actual vehicle images ,also if Driver / Passenger side mounting brackets are very identical in the design, suggest referring Parts Identification guide to avoid fitment issue.*

**3. Products are thumping / rattling after installation.**

*Ensure that all required mounting brackets / hardware's are installed & tighten correctly. Suggest using white lithium / regular grease between the metal to metal contact surfaces.*

**4. Side Bar is not aligning with vehicle / Step Pads are not aligning with vehicle doors.**

*Side bar may be interchanged or mounting brackets are not installed at the correct position in the vehicle. Refer Parts identification guide.*

**5. Missing / Excess Hardware.**

*Recheck hardware count as per the part list.*

**6. Product not installing properly.**

*Ensure make model year, cab length and bed size of your vehicle is listed in the application. All installation steps are followed correctly.*

**Check out these other TrailFX Products!!**

www.TrailFX.com

**SIDE BARS****ROCKER GUARD****HEADACHE RACKS****RUNNING BOARDS**

Keystone Automotive Operations Inc. (KAO) warrants this product to be free of defects in material and workmanship at the time of purchase by the original retail consumer. KAO disclaims any other warranties, express or implied, including the warranty of fitness for a particular purpose or an intended use. If the product is found to be defective, KAO may replace or repair the product at our option, when the product is returned prepaid, with proof of purchase. Alteration to, improper installation, or misuse of this product voids the warranty. KAO's liability is limited to repair or replacement of products found to be defective, and specifically excludes liability for any incidental or consequential loss or damage.