




# Full Length Hoop Step

Part No. A3222




Fits: 2009 - Current Dodge Ram 1500 Quad Cab (4Dr) 6.4' Bed



REMOVE CONTENTS FROM BOX. VERIFY ALL PARTS ARE PRESENT.



READ INSTRUCTIONS CAREFULLY BEFORE STARTING INSTALLATION.



DO NOT OVER TORQUE. STANDARD OPERATING LOAD FOR TIGHTEN BODY MOUNT NUTS & BOLTS VARIES FROM 45 TO 65 FOOT POUND.



30-40 min



Cutting Not  
Required



Drilling Not  
Required



[support@trailfx.com](mailto:support@trailfx.com)



1 866 638 4870



POLISHED STAINLESS STEEL – LIMITED LIFETIME  
POWDER COATED BLACK – 3 YEARS

## Bolt Kit

### PARTS LIST:

Qty	Part Description	Qty	Part Description
12	3/8" x 1" Hex Bolts	12	3/8" Threaded Clips
12	3/8" Washers		

### Tools Needed

Socket Set	
------------	--

## INSTALLATION PROCEDURE:

**Step 1.** Locate the driver's side Nerf Step; the shorter tail bend will be toward the front of the vehicle (see figure 2).

**Step 2.** Starting with the driver's side, locate the six factory mounting hex holes, which are positioned on the vertical wall of the floor pan below each door. Hex holes are arranged in sets of two, front, middle, and rear of vehicle.

**Step 3.** Locate the 3/8" threaded clips. Above each pair of hex holes find a rectangular opening. Slide two clips in each opening, positioning the clips so that the threads are visible through each hex hole (see figure 1).

**Step 4.** Align the Nerf Step brackets with each of the three sets of holes. Start a 3/8" x 1" hex bolt with washer through each bracket and into the threaded clip. Hand-tighten at this time.

**Step 5.** Starting with the front, push the Nerf Step up toward the pinch weld, and torque the forward most bolt to 15 – 20 ft. lb. Level the Nerf Step with the pinch weld, and torque the rear most bolt. Torque all remaining bolts to 15 - 20 ft. lb.

**Step 6.** Repeat steps 1 through 5 on passenger's side.



Figure 2

**PRODUCT CARE**

- Periodically check the product to ensure all fasteners are tight and components are intact.
- Regular waxing is recommended to protect the finish of the product.
- **Use ONLY Non-Abrasive automotive wax.** Use of any soap, polish or wax that contains an abrasive is detrimental and can scratch the finish leading to corrosion.
- Aluminum polish may be used to polish small scratches and scuffs for **Stainless Steel finish.**
- Mild soap may be used to clean the product for both **Stainless Steel and Black finish.**

**FAQ's****1. Hardware's are not of correct size.**

*In GMC / Chevrolet truck model 2006 & up, customer needs to reuse the factory body bolts to install the bracket. If your vehicle is not GMC / Chevrolet 2006 & up, ensure that holes are not partially covered with any plastic grommet or rust? If it is, remove the plastic grommet & rust from the thread holes & re-try the installation.*

**2. Mounting Bracket are not getting Installed properly.**

*In some cases Illustration images shown in Installation manual may not be the exactly same as per actual vehicle images ,also if Driver / Passenger side mounting brackets are very identical in the design, suggest referring Parts Identification guide to avoid fitment issue.*

**3. Products are thumping / rattling after installation.**

*Ensure that all required mounting brackets / hardware's are installed & tighten correctly. Suggest using white lithium / regular grease between the metal to metal contact surfaces.*

**4. Side Bar is not aligning with vehicle / Step Pads are not aligning with vehicle doors.**

*Side bar may be interchanged or mounting brackets are not installed at the correct position in the vehicle. Refer Parts identification guide.*

**5. Missing / Excess Hardware.**

*Recheck hardware count as per the part list.*

**6. Product not installing properly.**

*Ensure make model year, cab length and bed size of your vehicle is listed in the application. All installation steps are followed correctly.*

**Check out these other TrailFX Products!!**


**www.TrailFX.com**




**SIDE BAR**



**ROCKER GUARDS**



**HEADACHE RACKS**



**RUNNING BOARDS**

Keystone Automotive Operations Inc. (KAO) warrants this product to be free of defects in material and workmanship at the time of purchase by the original retail consumer. KAO disclaims any other warranties, express or implied, including the warranty of fitness for a particular purpose or an intended use. If the product is found to be defective, KAO may replace or repair the product at our option, when the product is returned prepaid, with proof of purchase. Alteration to, improper installation, or misuse of this product voids the warranty. KAO's liability is limited to repair or replacement of products found to be defective, and specifically excludes liability for any incidental or consequential loss or damage.