


# **Extreme Grille Guard**



| PARTS LIST: |                         |     |                  |
|-------------|-------------------------|-----|------------------|
| Qty         | Part Description        | Qty | Part Description |
| 2           | Bottom support brackets | 4   | M12 lock washer  |
| 10          | M12*45 hex head bolt    | 6   | M12 lock nuts    |
| 20          | M12 Enlarge flat washer | 4   | M12 hex nuts     |

## **INSTALLATION PROCEDURE:**

- Install bottom support brackets behind frame horn. Note: You must use regular M12 hex nuts and M12 lock washers on the 1. bolts going through truck frame! You will access the bolt head through a small hole located on the inside/bottom of truck frame when you are tightening.
- Mount grille guard to frame horn and Bottom Support Bracket using M12 lock nuts. Bolts will go through the grille guard 2. bracket and the frame horn on the front. Foot of grille guard on the bottom goes under bottom support bracket.
- Check alignment of grille guard to truck and tighten all bolts. 3.



#### PRODUCT CARE

- Periodically check the product to ensure all fasteners are tight and components are intact.
- Regular waxing is recommended to protect the finish of the product.
- Use ONLY Non-Abrasive automotive wax. Use of any soap, polish or wax that contains an abrasive is detrimental and can scratch the finish leading to corrosion.
- Aluminum polish may be used to polish small scratches and scuffs for Stainless Steel finish.
- Mild soap may be used to clean the product for both Stainless Steel and Black finish.

## FAQ's

1. Hardware's are not of correct size.

In GMC / Chevrolet truck model 2006 & up, customer needs to reuse the factory body bolts to install the bracket. If your vehicle is not GMC / Chevrolet 2006 & up, ensure that holes are not partially covered with any plastic grommet or rust? If it is, remove the plastic grommet & rust from the thread holes & re-try the installation.

2. Mounting Bracket are not getting Installed properly.

In some cases Illustration images shown in Installation manual may not be the exactly same as per actual vehicle images ,also if Driver / Passenger side mounting brackets are very identical in the design, suggest referring Parts Identification guide to avoid fitment issue.

# 3. Products are thumping / rattling after installation.

Ensure that all required mounting brackets / hardware's are installed & tighten correctly. Suggest using white lithium / regular grease between the metal to metal contact surfaces.

4. Side Bar is not aligning with vehicle / Step Pads are not aligning with vehicle doors. Side bar may be interchanged or mounting brackets are not installed at the correct position in the vehicle. Refer Parts identification guide.

## 5. Missing / Excess Hardware.


Recheck hardware count as per the part list.

6. Product not installing properly.

Ensure make model year, cab length and bed size of your vehicle is listed in the application. All installation steps are followed correctly.

## **Check out these other TrailFX Products!!**

## www.FX-Products.com



Keystone Automotive Operations Inc. (KAO) warrants this product to be free of defects in material and workmanship at the time of purchase by the original retail consumer. KAO disclaims any other warranties, express or implied, including the warranty of fitness for a particular purpose or an intended use. If the product is found to be defective, KAO may replace or repair the product at our option, when the product is returned prepaid, with proof of purchase. Alteration to, improper installation, or misuse of this product voids the warranty. KAO's liability is limited to repair or replacement of products found to be defective, and specifically excludes liability for any incidental or consequential loss or damage.