

INSTALLATION GUIDE FOR 52 mm GAUGE MOUNTING CUPS

For use with any mechanical or electrical gauge.




2650-1506-00

INSTALLATION:

1. Install mounting base using 2 sheet metal screws or stainless steel hose clamp (not included).
2. Attach strap loosely to base using (2) 10-32x1/2 screws with lockwashers and threaded spacer.
3. Slide gauge into the mounting cup and the mounting cup into the mounting strap and tighten the strap mounting screws.

NOTE: When using gauge mounting cups, studs on white plastic gauge case must be shortened approximately 6.35mm to 12.7mm.



SERVICE

For service send your product to STACK in a well packed shipping carton. Please include a note explaining what the problem is along with your phone number. Please specify when you need the product back. If you are sending product back for Warranty adjustment, you must include a copy (or original) of your sales receipt from the place of purchase.

12 MONTH LIMITED WARRANTY

STACK, Ltd. warrants to the consumer that all STACK products will be free from defects in material and workmanship for a period of twelve (12) months from date of the original purchase. Products that fail within this 12 month warranty period will be repaired or replaced at STACK's option to the consumer, when it is determined by STACK, Ltd. that the product failed due to defects in material or workmanship. This warranty is limited to the repair or replacement of parts in the STACK instruments. In no event shall this warranty exceed the original purchase price of the STACK instruments nor shall STACK, Ltd. be responsible for special, incidental or consequential damages or costs incurred due to the failure of this product. Warranty claims to STACK must be transportation prepaid and accompanied with dated proof of purchase. This warranty applies only to the original purchaser of product and is non-transferable. All implied warranties shall be limited in duration to the said 12 month warranty period. Breaking the instrument seal, improper use or installation, accident, water damage, abuse, unauthorized repairs or alterations voids this warranty. STACK, Ltd. disclaims any liability for consequential damages due to breach of any written or implied warranty on all products manufactured by STACK.

FOR COMPLETE OPERATIONS GUIDE PLEASE VISIT: WWW.STACKLTD.COM

Stack Ltd. Wedgwood Road Bicester OX26 4UL UK

T : +44 (0) 1869 240404

F: +44 (0) 1869 245500

E: sales@stackltd.com