



B&W Trailer Hitches

1216 Hawaii Road / PO Box 186

Humboldt, KS 66748

P:800.248.6564

F:620.869.9031

Call or Email us for
Installation Support
hitches@turnoverball.com
www.bwtrailerhitches.com

RV LIFTING DEVICE

RVXA3130

Follow all warnings and methods described in the installation instructions provided with the hitch base. Copies of these documents can be found at our web site: www.bwtrailerhitches.com or by calling 800-248-6564.

⚠ WARNING

Failure to comply with the safety information in these instructions could result in serious injury or death.

- ⚠ Read all installation and operating instructions along with all labels for any hoist used with the RV lifting device.
- ⚠ The RV lifting device is for use with B&W RV coupler products RVC3006 & RVC3200 only (B&W Companion and Patriot couplers).
- ⚠ Do not modify this product in any manner. Doing so could alter its integrity and lead to a loss of attachment between the product and coupler head.
- ⚠ This device is designed to be used in conjunction with a hoist that can safely lift the total weight of the B&W RV coupler and base (300 lbs minimum).

USING LIFTING DEVICE

1. **Place the RV lifting device.** Open the jaws of the coupler and place the lifting device as shown in the figure to the right. Close the jaws and pin the handle so it is secure.
2. **Attach hoist.** Attach a hoist to the eyelet at the top of the RV lifting device and ensure that it is secure.
3. **Un-attach Base from truck.** Depending on which base model you have; open the latch pin, un-pin the legs from the rails, or open the attachment points. Refer to the installation instructions provided with the base for complete instructions on un-attaching the base from the truck.
4. **Use the hoist to pull up on RV lifting device.** Slowly pull the coupler and base out of the attachment locations on the truck. As the base is lifted, make sure that it moves steadily up and without catching on any part of the hitch or truck, and without getting wedged in place due to uneven lifting.
5. **Move and lower hitch.** Carefully maneuver and lower the RV hitch to a secure stable area for storage. The full weight of the hitch must be resting on the surface holding the hitch and not the RV lifting device or hoist cable.

