



Stainless Steel Steering Column Mount

Secure steering column mount to floor or firewall.

Slide steering column through the column mount to desired position and then tighten the clamp screw.