



# Universal Oil Cooler Adapters

22-545 through 22-549



**Cooler Feed Port**  
oil from engine  
passes through adapter  
to the cooler

**Spin-on to engine side**



**Cooler Return Port**  
oil from cooler  
passes through adapter  
and on to filter

**Filtered oil back to engine**

**Install filter Side**