

If you have any comments or concerns,
please feel free to contact our
customer service department at:
Toll-free: 1-800-835-0438
OR
Email: info@gofia.com

SEAT COVERS
BY



FEATURING
SUPER-GRIP®
THE SLIP RESISTANT FASTENING SYSTEM

INSTALLATION INSTRUCTIONS
FOR
Oe38-20/ SL68-20/ SP88-20/ TR48-20


Thank you for purchasing one of our fine quality products. Your seat cover is engineered from high quality materials and designed with precision to give you a long-lasting, well-adjusted fit.

INSTRUCTIONS:

- A) BACKREST COVERS X 2 :**
1. Move seat to most forward position
 2. Pull cover down firmly
 3. Tuck flap through crevice and attach to velcro at back
- B) CUSHION COVER - 60 PORTION:**
1. Remove cup holder (see NOTE)
 2. Position cover over driver cushion
 3. Pass front straps under seat and buckle
 4. Pass side straps around the back of seat and buckle
 5. Secure velcro to carpet on seat
 6. Adjust all straps, buckles and velcro to equalize the tension
- C) CUSHION COVER - 40 PORTION:**
1. Position cover over passenger cushion
 2. Pass front strap under seat and buckle
 3. Pass side straps around the back of seat and buckle
 4. Adjust all straps and buckles to equalize the tension

NOTES:

1) **SELF-LOCKING SUPER-GRIP® BUCKLE:**



2) **REMOVING CUP HOLDER:**

- a) Press latch underneath cup holder
- b) Pull forward and remove
- c) Slide back in to re-install

WARNING: SEATS WITH INTEGRATED SEAT AIRBAGS MUST BE COVERED ONLY WITH SEATCOVERS DESIGNED WITH OPENINGS THAT WILL NOT INTERFERE WITH THE DEPLOYMENT OF THE AIRBAG.. NEVER INSTALL SEAT COVERS WITHOUT THESE OPENINGS AS THIS MAY INTERFERE WITH THE PROPER DEPLOYMENT OF THE AIR BAGS AND COULD RESULT IN SERIOUS INJURY.



Fia Inc. Winnipeg, Canada R3L 0N3 Telephone (204) 475-0515 Toll-Free: 1-800-835-0438
Fax: (204) 284-8246 E-Mail: info@gofia.com Website: www.gofia.com