


SEAT COVERS  
BY



If you have any comments or concerns,  
please feel free to contact our  
customer service department at:  
Toll-free: 1-800-835-0438  
OR  
Email: [info@gofia.com](mailto:info@gofia.com)

**FEATURING**  
**SUPER-GRIP®**  
**THE SLIP RESISTANT FASTENING SYSTEM**  
**INSTALLATION INSTRUCTIONS**  
**FOR**  
**OE39-8/ SL69-8/ SP89-8/ TR49-8**

Thank you for purchasing one of our fine quality products. Your seat cover is engineered from high quality materials and designed with precision to give you a long-lasting, well-adjusted fit.

**INSTRUCTIONS:**

**A) BACKREST COVER**


- 1) Remove head rest (see note)
- 2) Open velcro on the side seam to allow for fitting around armrest
- 3) Slip cover over backrest and pull down firmly
- 4) Fasten side velcro
- 5) Tuck flaps through crevice and attached to velcro at back
- 6) Adjust all velcro to equalize tension
- 7) Replace headrests (see note)

**B) CUSHION COVER**

- 1) Center cushion cover on seat
- 2) Pass the front strap under the seat and buckle to the back flap of cover
- 3) Pass side straps through the opening between the molded plastic and the seat and buckle to back flap of cover
- 4) Adjust straps and buckles to equalize tension

**NOTES:**

**1) SELF-LOCKING SUPER-GRIP® BUCKLE:**



**3) RE-INSTALLATION OF HEADRESTS**

- A) Ensure pre-cut holes in seat cover align with holes in base.
- B) Replace headrests


**2) HEAD REST REMOVAL:**

- A) - Insert paper clip into holes at base to release
  - Lift off

**OR**

- B) - Push in side release buttons
  - Lift off

(If unable to remove consult dealership)



**WARNING: SEATS WITH INTEGRATED SEAT AIRBAGS MUST BE COVERED ONLY WITH SEATCOVERS DESIGNED WITH OPENINGS THAT WILL NOT INTERFERE WITH THE DEPLOYMENT OF THE AIRBAG.. NEVER INSTALL SEAT COVERS WITHOUT THESE OPENINGS AS THIS MAY INTERFERE WITH THE PROPER DEPLOYMENT OF THE AIR BAGS AND COULD RESULT IN SERIOUS INJURY.**

