




757-842-6497
WWW.JLOSC.COM

**J&L Oil Separator 3.0 Passenger Side (2007-14 GT500 – Remote Mount)
#3040P Installation Instructions**

**Check out the install video of this product on our website www.JLosc.com
Search:3040P and click videos**

Please review complete instructions prior to installing.

Step#	
1	Verify you have all the following parts included in the kit: (1) J&L Oil Separator/hose assembly (1) J&L Mounting bracket, (2) Fine thread machine screws, (1) Grounding stud, (1) M6 nut
2	Gather all the following tools needed for the installation: Phillips screwdriver & 10mm socket/ratchet
3	Remove stock PCV line by pulling on the grey clips. 
4	Remove the ground bolt and use SUPPLIED grounding stud and nut to mount J&L bracket to the shock tower. IMPORTANT! Ground strap must go between J&L stud and body to still make the ground. Like shown below.  <div data-bbox="954 1539 1446 1766" style="border: 1px solid black; padding: 5px; display: inline-block;"><p><u>NUT</u> <u>BRACKET</u> <u>GROUNDING STUD</u> <u>GROUND STRAP</u></p></div>

		
	2007-09 2010-14	
5	Using the supplied M4x10 screws to mount the Oil Separator to the bracket	
6	Connect the quick connect hoses and you are done. 	

To properly clean the filter in the Oil Separator, spray any degreaser or solvent through it and let it air dry. Clean it every 10,000 miles.

Thank you for your business. If you have any questions, please e-mail info@JLosc.com or call 757-842-6497. Our hours are Monday-Friday. 8:00am – 4:30pm Eastern Time.

J&L Oil Separator co. Lifetime Satisfaction Guarantee. We want you to be a J&L customer for life! Your new J&L product is warranted to be free from defects in materials and workmanship for the life of the *original retail purchaser*, subject to the limitations contained in our warranty found here. www.JLosc.com/warranty

We guarantee workmanship and even a pathway to discounted upgrades for substantially improved items.

Return Policy: All returns will be subject to a 10%-25% restocking fee. Please visit www.JLosc.com for complete return policy.

Disclaimer: J&L Oil Separator co. makes no warranties whatsoever, expressed, or implied, oral or written to any purchasers, except the warranty above. J&L Oil Separator co. hereby specifically excludes from any implied warranty of merchantability or implied warranty of incidental, secondary, or consequential damages of any kind whatsoever. All purchasers and users of products manufactured by J&L Oil Separator co. agree to hold harmless and indemnify J&L Oil Separator co. from any and all claims arising from their use. Failure to receive notice of any or the limitations contained in this disclaimer shall not serve to extend liability to J&L Oil Separator co. for any claims arising out of use of its products.