



Throttle Body Spacer Installation Instructions

Toyota 2.4L

Part #62161 & 62164

- 1. Remove the Air Cleaner lid by removing the two bolts that mount it to the base of the Air Cleaner assembly and unplug any wiring attached to the lid.**
- 2. Remove the air intake tube from the throttle body by squeezing the clamp that holds it to the throttle body.**
- 3. Remove the 4 bolts that mount the throttle body to the intake manifold.**
- 4. Install the JET Power-Flo spacer placing the gasket between the throttle body and the spacer with the supplied longer bolts and washers.**
- 5. Reinstall the Air Intake assembly.**

JET Performance Products – 17491 Apex Circle – Huntington Beach, CA 92647

Phone 714-848-5515 Fax 714-847-6290