

Toyota Mass Air Flow Installation Instructions Part #69145

- 1. Locate the factory Mass Air Flow sensor located in the air intake tube of the vehicle.**
- 2. Remove the two screws that mount the factory Mass Air Flow Sensor to the air intake tube.**
- 3. Install the JET Powr-Flo Mass Air Sensor in the intake tube using the factory screws that you previously removed.**
- 4. Start vehicle and verify that the check engine light is not on.**
- 5. Put your factory sensor away in a safe place for a spare.**