



# INSTALLATION INSTRUCTIONS

## Part Number: TB-1216

This filter fits: SEE CATALOG FOR CURRENT APPLICATIONS

\* FREE K&N® decal To register your warranty, please see us online at [knfilters.com/register](http://knfilters.com/register). FREE K&N® decal \*

Congratulations, you have purchased the finest air filter that money can buy. With proper care, this filter will last 1 million miles or more. This filter is a direct replacement for the stock air filter, and no modification will be required. However the following procedures MUST be followed to ensure the proper fit and seal of the K&N® air filter.

**If you need any assistance please call 1-800-858-3333 to speak with a representative in our Customer Service Center before returning the product.**

### INSTALLATION:

1. Remove the dirty filter.
2. Carefully clean the inside of the air box and sealing surfaces.
3. Apply a bead of K&N® air filter sealing grease to the lip seal of the K&N® filter as shown. (Fig.1)

**NOTE: Grease included with filter. (99-0703-1)**

4. Install K&N® filter into air box tray in the correct orientation. (Fig.2)
5. Push the tray with the filter in the air box completely (Fig.3) then wipe off any excess grease. (Fig.4)
6. Reinstall the filter cover to complete installation.

**THESE INSTRUCTIONS MUST BE FOLLOWED EVERY TIME THE FILTER IS SERVICED, OTHERWISE THE FILTER MAY NOT SEAL, AND DAMAGE TO THE ENGINE COULD RESULT.**



Fig.1



Fig.2



Fig.3



Fig.4

### CLEANING:

K&N Engineering, Inc., suggests checking the air filter element periodically for excessive dirt build-up. Depending on your driving conditions, we recommend cleaning your air filter every 50,000 miles. To clean and re-oil, purchase our filter Recharger® service kit, part number 99-5050 or 99-5000 and follow the easy instructions.