

IMPORTANT

**SUBMERGE THE OIL PUMP IN
CLEAR OIL AND REVOLVE BY
HAND BEFORE INSTALLATION
IN THE ENGINE.**