

STEELCRAFT

INSTALLATION INSTRUCTIONS
TAILLIGHT GUARD PART # T7766
2005 NISSAN FRONTIER

PARTS LIST

- (1)- TAILLIGHT GUARD PASSENGER SIDE
- (1)- TAILLIGHT GUARD DRIVER SIDE
- (2)- SUPPORT BRACKETS
- (2)- # 6 x 1/2" SCREWS, (2)- 1/4 SCREWS, (2)- 1/4 WASHERS

INSTALLING TAILLIGHT GUARD

- 1) START WITH THE PASSENGER SIDE, OPEN THE REAR GATE AND REMOVE THE SCREWS SECURING THE TAIL LIGHT TO THE BODY.
- 2) CAREFULLY UNSNAP THE TAIL LIGHT UNTIL IT IS FREED FROM THE HOUSING.
- 3) ATTACH THE SUPPORT BRACKET TO THE EXISTING HOLE BY USING THE 1/4 x 3/4" SCREW, 1/4 WASHER AND 1/4 HEX NUT.
- 4) SNAP THE TAIL LIGHT ASSEMBLY BACK INTO BODY.
- 5) POSITION REAR TAILLIGHT GUARD OVER TAIL LIGHT, MAKING SURE THAT THE MOUNTING BRACKETS ON THE TAILLIGHT GUARD ARE SEATED WHERE THE TAIL LIGHT SCREWS WERE FORMERLY LOCATED.
- 6) SECURE ASSEMBLY TO JAMB USING THE EXISTING SCREWS. SUPPORT BRACKET USE THE # 6 x 1/2" SCREWS.
- 7) RE-PEAT STEPS 1 THROUGH 6 ON THE DRIVER SIDE.

CUSTOMER SERVICE TOLL FREE (888) 800-ARIES