



# ORACLE LIGHTING

## RAM TOW MIRRORS

### ORACLE PART #5922

### INSTALLATION GUIDE

**TOOLS NEEDED:**  
FLAT-HEAD SCREWDRIVER  
PANEL TOOL  
10MM SOCKET  
ELECTRICAL TAPE



### STEP: 1A

SCAN QR CODE TO  
WATCH FULL INSTALL VIDEO




### STEP: 1B

SCAN QR CODE TO  
WATCH DOOR PANEL REMOVAL



BEGIN BY FOLDING THE MIRROR IN,  
TOWARDS THE VEHICLE.




USING A PANEL TOOL, START AT THIS EDGE & BEGIN  
REMOVING THE MIRROR ARM COVER.



WORK YOUR WAY DOWN THE MIRROR, CONTINUALLY  
SEPARATING THE MIRROR ARM COVER.



WITH THE MIRROR ARM COVER REMOVED, YOU  
CAN NOW ACCESS THE MIRROR HARNESS.



USING ELECTRICAL TAPE, ATTACH THE ORACLE MIRROR  
POWER CABLE TO THE OEM MIRROR HARNESS.






# ORACLE LIGHTING

## RAM TOW MIRRORS


### ORACLE PART #5922

### INSTALLATION GUIDE


**TOOLS NEEDED:**  
FLAT-HEAD SCREWDRIVER  
PANEL TOOL  
10MM SOCKET  
ELECTRICAL TAPE




**7**  
PULL THE SLACK OF THE MIRROR HARNESS THROUGH THE DOOR WITH THE ORACLE MIRROR CABLE ATTACHED.



**8**  
PULL HARNESS SLACK BACK THROUGH. SNAP IN ORACLE MIRROR ARM COVER.



**9**  
FEED THE ORACLE MIRROR POWER CABLE THROUGH THE SIDE OF THE DOOR & INTO THE ENGINE BAY.



**10**  
RUN MIRROR POWER CABLE INTO THE ENGINE BAY. CONNECT TO DESIRED AUX SWITCH OUTPUT.



**ORACLE**  
LIGHTING

[www.oraclelights.com](http://www.oraclelights.com)

© 2023 ORACLE LIGHTING

4401 Division St.  
Metairie, LA 70002

FOR ADDITIONAL TECHNICAL SUPPORT PLEASE CALL US 1(800)407-5776