



ORACLE LIGHTING

BRONCO LASER/LED FOG


ORACLE PART 5928-LZZ-001

INSTALLATION GUIDE


TOOLS NEEDED:

- T-40 TORX
- 10MM SOCKET
- SOCKET WRENCH


SCAN TO WATCH
INSTALL VIDEO




REMOVE THE (2) PANEL CLIPS.



PULL PANEL BACK SLIGHTLY.



USE T-40 TORX & SOCKET WRENCH TO LOOSEN
THE (4) SCREWS.



SLIDE IN FOG LIGHT MODULE FROM BEHIND THE BUMPER.




LINE UP FOG MODULE, RE-INSTALL SCREWS
FINGER TIGHT.



TIGHTEN DOWN THE (4) T-40 TORX SCREWS.



REPEAT STEPS (3-6) ON RH SIDE.
PUSH PANEL BACK INTO PLACE.



RE-INSTALL PANEL CLIPS.



www.oraclelights.com

© 2023 ORACLE LIGHTING

4401 Division St.
Metairie, LA 70002

FOR ADDITIONAL TECHNICAL SUPPORT PLEASE CALL US 1(800)407-5776









ORACLE LIGHTING

BRONCO LASER/LED FOG

ORACLE PART 5928-LZZ-001

INSTALLATION GUIDE

TOOLS NEEDED:
 T-40 TORX
 10MM SOCKET
 SOCKET WRENCH
 SCAN TO WATCH
 INSTALL VIDEO



Disclaimer:
 Buyer acknowledges that the laser function of this light is not intended for road use and will only be used in an appropriate manner off-road. Buyer is solely responsible for any claims arising out of Buyer's non-compliance with this provision.



www.oraclelights.com

© 2023 ORACLE LIGHTING

4401 Division St.
 Metairie, LA 70002

FOR ADDITIONAL TECHNICAL SUPPORT PLEASE CALL US 1(800)407-5776