TRAILFX®

5" Oval Nerf Bar
Part No. A7010S/B

Fits: **2005-Current**   **Toyota Tundra Double Cab**


60-180 min | Cutting Not Required | Drilling Not Required

REMOVE CONTENTS FROM BOX. VERIFY ALL PARTS ARE PRESENT.

✉ **support@trailfx.com**

READ INSTRUCTIONS CAREFULLY BEFORE STARTING INSTALLATION.

📞 **1 866 638 4870**

DO NOT OVER TORQUE. STANDARD OPERATING LOAD FOR TIGHTEN BODY MOUNT NUTS & BOLTS VARIES FROM **45** TO **65** FOOT POUND.

WARRANTY **POLISHED STAINLESS STEEL – LIMITED LIFETIME**
POWDER COATED BLACK – 3 YEARS

PARTS LIST:

Qty	Part Description	Qty	Part Description
1	Driver Sidebar	1	Driver/Left Rear Mounting Bracket
1	Passenger Sidebar	1	Passenger/Right Rear Mounting Bracket
1	Driver/Left Front Mounting Bracket	24	8-1.25mm x 30mm Hex Bolts
1	Passenger/Right Front Mounting Bracket	24	8mm Lock Washers
1	Driver/Left Middle Mounting Bracket	24	8mm ID x 24mm OD x 2mm Flat Washers
1	Passenger/Right Middle Mounting Bracket		

Passenger/Right Rear Mounting Bracket

Driver/Left Rear Mounting Bracket

Passenger/Right Center Mounting Bracket

Driver/Left Center Mounting Bracket

Passenger/Right Front Mounting Bracket

Driver/Left Front Mounting Bracket

Threaded insert locations to help determine correct Sidebar

**Front**

INSTALLATION PROCEDURE:

1. Starting on the driver side front of the vehicle, remove the existing (2) factory bolts, (or plastic plugs), on the side panel located by the front tire opening, **(Figure 1)**. This will be the mounting location for the driver side front Mounting Bracket. Partially attach the front Mounting Bracket to the vehicle using the included (2) 8mm x 30mm Hex Bolts, (2) 8mm Lock Washers and (2) 8mm Flat Washers, **(Figure 2)**. Do not tighten hardware at this time.

2. Remove the two factory bolts, (or plastic plugs), along the side panel closest to the front Bracket and the very last two factory bolts, (or plastic plugs), along the side panel toward the back of the cab. Select the proper Center and Rear Brackets and bolt them to the body panel as described in Step 2, **(Figures 3 - 5)**.

3. Carefully place the Driver/Left Sidebar onto the (3) Brackets. Align the threaded holes in the bottom of the Sidebar with the holes on the Mounting Brackets. Attach the Sidebar to the Mounting Brackets with the included (6) 8mm x 30mm Hex Bolts, (6) 8mm Lock Washers and (6) 8mm Flat Washers, **(Figures 3 - 5)**. Do not tighten at this time.

4. Level and adjust the Sidebar properly and tighten all hardware.

5. Repeat Steps 2-5 for passenger Sidebar installation.

6. Do periodic inspections to the installation to make sure that all hardware is secure and tight.

Driver Side Installation Pictured

Front

Remove plastic plugs (if equipped) or hex bolts from threaded holes

(Fig 1) Driver/Left Front Mounting Location Pictured

8mm x 30mm Hex Bolts
8mm Lock Washers
8mm Flat Washers

Fig 2

Front

There are four sets of threaded holes in the side panel. Starting from the front of the vehicle, use the first, second, and fourth set of holes.

Front

(Fig 3) Driver/Left Center Mounting Location Pictured

8mm x 30mm Hex Bolts
8mm Lock Washers
8mm Flat Washers

Front

(Fig 4) Driver/Left Center Bracket Pictured

Driver Side Installation Pictured

8mm x 30mm Hex Bolts
8mm Lock Washers
8mm Flat Washers

Rear

**(Fig 5) Driver/Left Rear Bracket Pictured**

Complete Installation

PARTS IDENTIFICATION GUIDE

Driver Side tube packed using "Green" color foam sheet. Passenger Side tube packed using "White" color foam sheet

No.	Parts Identification
1	Passenger / Right 'Rear' Bracket marked "**PR**"
2	Driver / Left 'Rear' Bracket marked "**DR**"
3	Passenger / Right 'Center' Bracket marked "**PC**"
4	Driver / Left 'Center' Bracket marked "**DC**"
5	Passenger / Right 'Front' Bracket marked "**PF**"
6	Driver / Left 'Front' Bracket marked "**DF**"

Note:
- *This guide is to identify the parts and not a reference for part count.*
- *For part count, refer Parts List.*
- *Product / Bracket image is representative and actual design may vary.*

PRODUCT CARE

- Periodically check the product to ensure all fasteners are tight and components are intact.
- Regular waxing is recommended to protect the finish of the product.
- **Use ONLY Non-Abrasive automotive wax.** Use of any soap, polish or wax that contains an abrasive is detrimental and can scratch the finish leading to corrosion.
- Aluminum polish may be used to polish small scratches and scuffs for **Stainless Steel finish.**
- Mild soap may be used to clean the product for both **Stainless Steel and Black finish.**

FAQ's

1. **Hardware's are not of correct size.**
   In GMC / Chevrolet truck model 2006 & up, customer needs to reuse the factory body bolts to install the bracket. If your vehicle is not GMC / Chevrolet 2006 & up, ensure that holes are not partially covered with any plastic grommet or rust? If it is, remove the plastic grommet & rust from the thread holes & re-try the installation.

2. **Mounting Bracket are not getting Installed properly.**
   In some cases Illustration images shown in Installation manual may not be the exactly same as per actual vehicle images ,also if Driver / Passenger side mounting brackets are very identical in the design, suggest referring Parts Identification guide to avoid fitment issue.

3. **Products are thumping / rattling after installation.**
   Ensure that all required mounting brackets / hardware's are installed & tighten correctly. Suggest using white lithium / regular grease between the metal to metal contact surfaces.

4. **Side Bar is not aligning with vehicle / Step Pads are not aligning with vehicle doors.**
   Side bar may be interchanged or mounting brackets are not installed at the correct position in the vehicle. Refer Parts identification guide.

5. **Missing / Excess Hardware.**
   Recheck hardware count as per the part list.

6. **Product not installing properly.**
   Ensure make model year, cab length and bed size of your vehicle is listed in the application. All installation steps are followed correctly.

Check out these other TrailFX Products!!   **www.TrailFX.com**

BULL BAR   **GRILLE GUARDS**   **BED RAILS**   **RUNNING BOARDS**